

# THE FURNITURE PAINT

## VARNISH: HOW TO APPLY

<b>USE</b>	For use on cabinetry, furniture, trim, millwork, etc.
<b>PROJECT PREP</b>	Unfinished surfaces should be sanded with 120 grit prior to applying varnish. Ensure project is free of dust, dirt, conditioners and oils. Remove any sanding dust with tack cloth.
<b>PRODUCT PREPARATION</b>	Shake vigorously for 30 seconds. Stir well making sure to incorporate materials at bottom of can. Stir before and during use.
<b>COVERAGE</b>	1 Quart treats ~100 SQ FT of smooth wood.
<b>APPLICATION</b>	Varnish may be applied with a roller, sprayer or brush. Product looks milky when first applied but dries clear. To avoid bubbles, do not over brush. Use a damp sponge brush to remove any bubbles on the wood's surface. Apply in a well-ventilated area. When using a spray gun, varnish may be thinned up to 10% with water. Do not apply in temperatures below 55°F.
<b>RECOAT</b>	For superior protection, apply up to three coats of varnish, especially in high traffic or water-exposed areas. Apply 2nd coat within 4 hours of applying 1st coat or wait 48 hours.
<b>DRY TIME</b>	Varnish is dry to touch in 60-120 minutes.
<b>CURE TIME</b>	Full cure time 30 days.
<b>CLEAN UP</b>	Easy soap and water clean up.

